


PREGADOR PNEUMÁTICO GRAMPAC CN100



Aplicar a trava rosca loctite 242

1	CN10001IMP	PARAFUSO (CN10001IMP)	46	CN10046IMP	PARAFUSO (CN10046IMP)	76	CN10076IMP	REGULADOR DO MAGAZINE (CN10076IMP)
2	CN10002IMP	DEFLETOR (CN10002IMP)	47	CN10047IMP	GUIA DA TRAVA (CN10047IMP)	77	CN10077IMP	TAMPA DO MAGAZINE (CN10077IMP)
3	CN10003IMP	CALCO (CN10003IMP)	48	CN10048IMP	CALCO (CN10048IMP)	78	CN10078IMP	PINO DO MAGAZINE (CN10078IMP)
4	CN10004IMP	PARAFUSO (CN10004IMP)	49	CN10049IMP	PINO (CN10049IMP)	79	CN10079IMP	PINO (CN10079IMP)
5	CN10005IMP	TAMPA (CN10005IMP)	50	CN10050IMP	JUNTA DO MANCAL (CN10050IMP)	80	CN10080IMP	PRESILHA DO MAGAZINE (CN10080IMP)
6	CN10006IMP	ANEL DE METAL (CN10006IMP)	51	CN10051IMP	MANCAL (CN10051IMP)	81	CN10081IMP	SUPORTE DA PRESILHA (CN10081IMP)
7	CN10007IMP	AMORTECEDOR DE EXAUSTAO (CN10007IMP)	52	CN10052IMP	PARAFUSO (CN10052IMP)	82	CN10082IMP	BUCHA (CN10082IMP)
8	CN10008IMP	MOLA DA TAMPA (CN10008IMP)	53	CN10053IMP	TRAVA DO MANCAL (CN10053IMP)	83	CN10083IMP	PINO (CN10083IMP)
9	CN10009IMP	O RING (CN10009IMP)	54	CN10054IMP	MOLA (CN10054IMP)	84	CN10084IMP	PROTETOR DO BICO (CN10084IMP)
10	CN10010IMP	O RING (CN10010IMP)	55	CN10055IMP	TAMPA DO MANCAL (CN10055IMP)	85	CN10085IMP	ARRUELA (CN10085IMP)
11	CN10011IMP	VALVULA (CN10011IMP)	56	CN10056IMP	PINO ELASTICO (CN10056IMP)	86	CN10086IMP	PORCA (CN10086IMP)
12	CN10012IMP	SELO DA VALVULA (CN10012IMP)	57	CN10057IMP	MOLA (CN10057IMP)	87	CN10087IMP	PARAFUSO (CN10087IMP)
15	CN10015IMP	CILINDRO (CN10015IMP)	58	CN10058IMP	O RING (CN10058IMP)	88	CN10088IMP	PARAFUSO (CN10088IMP)
16	CN10016IMP	O RING (CN10016IMP)	59	CN10059IMP	SUPORTE (CN10059IMP)	89	CN10089IMP	PORCA (CN10089IMP)
17	CN10017IMP	VEDANTE DO CILINDRO (CN10017IMP)	60	CN10060IMP	PINO (CN10060IMP)	90	CN10090IMP	PINO (CN10090IMP)
18	CN10018IMP	JUNTA (CN10018IMP)	61	CN10061IMP	ALIMENTADOR (CN10061IMP)	91	CN10091IMP	SUPORTE DO MAGAZINE (CN10091IMP)
19	CN10019IMP	CORPO (CN10019IMP)	62	CN10062IMP	O RING (CN10062IMP)	92	CN10092IMP	PARAFUSO (CN10092IMP)
21	CN10021IMP	O RING (CN10021IMP)	63	CN10063IMP	MOLA DO ALIMENTADOR (CN10063IMP)	93	CN10093IMP	O RING (CN10093IMP)
22	CN10022IMP	NIPLE (CN10022IMP)	64	CN10064IMP	PINO DO ALIMENTADOR (CN10064IMP)	94	CN10094IMP	ARRUELA (CN10094IMP)
23	CN10023IMP	PINO DO ENGATE (CN10023IMP)	65	CN10065IMP	BRACO DO ALIMENTADOR (CN10065IMP)	95	CN10095IMP	VALVULA (CN10095IMP)
24	CN10024IMP	PINO ELASTICO (CN10024IMP)	66	CN10066IMP	O RING (CN10066IMP)	96	CN10096IMP	O RING (CN10096IMP)
25	CN10025IMP	PINO ELASTICO (CN10025IMP)	67	CN10067IMP	PISTAO DO ALIMENTADOR (CN10067IMP)	102	CN100102IMP	CONJUNTO PISTAO MARTELO C/ANEL (CN100102IMP)
26	CN10026IMP	CONTATO GATILHO (CN10026IMP)	68	CN10068IMP	O RING (CN10068IMP)	103	CN100103IMP	VALVULA SUPERIOR C/ANEIS (CN100103IMP)
34	CN10034IMP	MOLA (CN10034IMP)	69	CN10069IMP	PARAFUSO (CN10069IMP)	104	CN100104IMP	VALVULA COM ANEIS (CN100104IMP)
39	CN10039IMP	CONJUNTO GATILHO (CN10039IMP)	70	CN10070IMP	BATENTE (CN10070IMP)	105	CN100105IMP	PINO DA VALVULA C/ANEIS (CN100105IMP)
40	CN10040IMP	CALCO DO CILINDRO (CN10040IMP)	71	CN10071IMP	MOLA (CN10071IMP)	106	CN100106IMP	ANEL O RING (CN100106IMP)
41	CN10041IMP	AMORTECEDOR SUPERIOR (CN10041IMP)	72	CN10072IMP	CHAPEU (CN10072IMP)	107	CN100107IMP	CHAPEU DA VALVULA (CN100107IMP)
42	CN10042IMP	AMORTECEDOR INFERIOR (CN10042IMP)	73	CN10073IMP	ANEL DE ELASTICO (CN10073IMP)	109	CN100109IMP	PINO (CN100109IMP)
43	CN10043IMP	TRAVA DE SEGURANCA (CN10043IMP)	74	CN10074IMP	MAGAZINE (CN10074IMP)	110	CN100110IMP	TAMPA DA VALVULA (CN100110IMP)
44	CN10044IMP	MOLA (CN10044IMP)	75	CN10075IMP	DISCO DO MAGAZINE (CN10075IMP)			

Versão: 05.23

DOCUMENTO SUJEITO Á ALTERAÇÕES SEM PRÉVIO AVISO

